


# SPECIAL *Event* RENTALS

## How to Light the Pilot Light on the Optima Deepfryer



Pilot



Pilot Dial

1. Turn dial to vertical position.
2. Press and Hold.
3. Light pilot light with barbecue lighter.
4. When there is a steady flame keep pressing for 45 seconds to heat up the thermocouple, then turn pilot light to the on position and set temperature to desired heat.

**Edmonton**  
780-435-2211  
6010-99 Street

**Red Deer**  
403-347-7733  
5929-48 Ave

**Calgary**  
403-235-2211  
2312-52 Ave

**Banff**  
403-762-2227  
150 Eagle Crescent